



GEBERIT AQUACLEAN TUMA COMFORT



QUICK GUIDE



971.181.00.0(02)

For your safety

What should you avoid?

The product must be used as intended. Do not:

- leave the WC seat ring during the shower procedure
- place loads or objects on the WC lid
- immerse the remote control in liquid
- operate without plug for Geberit AquaClean descaling agent

Register your device

Warranty registration

Extend the warranty period of your Geberit AquaClean for free. Register for this within 90 days from the installation date.



In the third year of the warranty period, Geberit shall supply spare parts free of charge in the event of any material or manufacturing faults, provided the product has been installed and put into operation by an installation company.

By web link:

<https://www.geberit-global.com/landingpages/gac-onboarding/>

By smartphone or tablet:



Android:



iOS:




Via the Geberit Home App:



If your country is not listed on the onboarding web page, please consult the list of contact information and websites. → See "Contact".

Getting to know your device

The device at a glance



- 1 WC lid
- 2 Remote control with magnetic wall-mounted holder
- 3 WC seat ring with user recognition and WC seat ring heating
- 4 Lateral control panel with status LED
- 5 Spray arm with spray nozzle and Lady shower nozzle
- 6 Dryer flap
- 7 Spray shield
- 8 Geberit AquaClean cleaning set (art. no. 242.547.00.1)
- 9 Geberit AquaClean descaling agent (art. no. 147.040.00.1)



- 1 Filling opening with plug for Geberit AquaClean descaling agent
- 2 Power switch
- 3 Specification plate with serial number
- 4 Design cover
- 5 Back of the device: Filter compartment cover
- 6 Back of the device: Replaceable Geberit ceramic honeycomb filter type 3 (art. no. 242.999.00.1)

Some components and the consumables listed below can be ordered directly via the Geberit Home app or via the Geberit Web Shop.

Consumables	Article number
Geberit AquaClean cleaning set	242.547.00.1
Geberit AquaClean descaling agent	147.040.00.1
Geberit AquaClean descaling agent set (4 pcs)	147.047.00.1
Geberit AquaClean descaling agent set (10 pcs)	147.048.00.1
AquaClean Tuma spray nozzle	243.527.11.1
AquaClean Tuma remote control	245.999.01.1

Operating concept

About the operating concept


The shower toilet can be operated via remote control, the lateral control panel on the shower toilet and the Geberit Home App.



The remote control function of the Geberit AquaClean shower toilet is deactivated while the shower toilet is connected to the Geberit Home App.

Front side of the remote control

All functions for daily use can be operated from the front side of the remote control.



- 1 <Shower> button:
 - start and stop the spray functionality
 - stop dryer functionality and Lady shower
- 2 <+>/<-> buttons: increase or decrease the spray/dryer air intensity
- 3 <Up>/<down> arrow keys: set spray arm position (spray arm forwards/backwards)
- 4 <Lady shower> button: start and stop the Lady shower
- 5 <Dryer> button: start and stop the dryer
- 6 <Odour extraction> button: Start and stop odour extraction
- 7 <User profile> buttons: select the user profiles 1–3
- 8 Status LED (only visible if necessary)

Rear side of the remote control

You can access different settings and additional functions from the rear side of the remote control.




To extend the battery life, the display switches to standby mode after a certain time.



When using a remote control manufactured from 2024 onwards with an older firmware version on the unit, not all functions are available:

- Display only shows 2 lines
- No LED display on the front of the remote control
- Functions not available using the three preset buttons
- OK button function not available


To be able to use all functions, update the firmware with the Geberit Home app (FW version $\geq$ v 13.0).



- | | |
|---|--|
| 1 | Battery compartment |
| 2 | Ink display |
| 3 | <Temperature> preset button |
| 4 | <Home> preset button |
| 5 | <Care and maintenance> preset button |
| 6 | <up>/<down>, <left>/<right> arrow keys |
| 7 | <OK/save> button |

Lateral control panel

The shower toilet functions of the device can be operated from the lateral control panel.



- 1 <+>/<-> buttons: Increase or decrease the spray intensity.
- 2 Status LED
- 3 <Shower> button: Start or stop the anal shower or the Lady shower.

Downloading the Geberit Home app

Download the Geberit Home app free of charge from the respective App-Store:

- 1 Open the App-Store on your smartphone.
- 2 Enter 'Geberit Home' in the search field.
 - ✓ The Geberit Home app is displayed.



3

Download the app.

- ✓ The app is downloaded and displayed on your smartphone.

Alternatively, you can scan the respective QR code to download the Geberit Home app:

[Android:](#)



[iOS:](#)



How to use the device

Using the anal shower

i See user manual.




972.475

<https://doc.geberit.com/972.475.00.0>

Prerequisite

- You are sitting down on the WC seat ring.

- Briefly press the <Shower> button on the lateral control panel or on the remote control once.



Result

- ✓ The shower procedure starts.
- ✓ The anal shower starts in oscillating function. A small amount of water drains into the WC ceramic appliance via the overflow. The anal shower is active for 50 seconds.

i You can stop the shower procedure early by pressing the <Shower> button once again.


Use the Lady shower

i The woman's intimate area is a very sensitive zone and requires special and prudent care. The Lady shower must be set to your ergonomic conditions to achieve an optimal cleaning result. The position of the spray nozzle and the spray intensity must be selected so that the shower spray cannot penetrate the vagina.


Prerequisite

- You are sitting down on the WC seat ring.

- 1** Press the <Lady shower> button on the remote control.



- 2** Or: Press the <Shower> button on the lateral control panel for 2 seconds.



Result

- ✓ The Lady shower starts.


i You can stop the shower procedure early by pressing the <Shower> button once again.

Set the spray intensity

Prerequisite

- The shower procedure is running.

- ▶ Press the <+> button to increase the spray intensity. Press the <-> button to decrease the spray intensity.



Result

- ✓ The shower spray becomes stronger/weaker.

- i** You can set the spray intensity in 5 stages.


Set the spray arm position

- i** Female users should set the spray arm position of the spray functionality to their ergonomic conditions so that it does not compromise the natural protection of the vaginal area.

Prerequisite

- The shower procedure is running.

- ▶ Press the arrow keys on the remote control to position the spray arm.
 - ✓ The spray arm moves forwards or backwards.



Result

- ✓ The spray arm is optimally positioned.

- i** You can set the spray arm position in 5 stages.


Switching the oscillating motion of the anal shower on and off

- i** The oscillating motion of the spray arm increases the cleaning effect.

Prerequisite

- The shower procedure is running.

- ▶ Press the <up> and <down> arrow keys at the same time to switch the oscillating motion off and on during the shower procedure.




Switch dryer on and off

- i** The drying procedure starts automatically according to the factory settings as soon as the shower procedure has finished. The automatic drying procedure can be switched off in the basic profile and then started manually.

Prerequisite

- You are sitting down on the WC seat ring.
- The shower procedure is running.

- ▶ Press the <Dryer> button.



Result

- ✓ The drying procedure starts and runs for 5 minutes.

- i** You can stop the drying procedure early by pressing the <Dryer> button once again.

Saving user profiles

Three different user profiles can be stored via the <user profile> buttons on the remote control.




User profiles allow you to access your personal settings directly. Select your user profile as soon as you sit down.

1

Enter your personal settings.

2

Press one of the 3 <user profile> buttons for more than 2 seconds.



Result

- ✓ The device beeps (1x).
- ✓ The LED on the remote control briefly lights up green.
- ✓ The current settings are saved to this button.



The following functions can only be configured from the rear side of the remote control:

- WC seat ring heating
 - shower water temperature
 - warm air temperature
- See user manual.

Saving a personal user profile in the Geberit Home App

Prerequisite

- The current version of the Geberit Home app is installed on your smartphone.
- The Geberit Home app is running.
- You are within the detection range of the shower toilet. User recognition does not have to be activated.

1

Enter your personal settings.

2

Save your settings in the Geberit Home app.

Result

- ✓ Your personal user profile is saved onto your smartphone.
- ✓ The settings apply to all connected shower toilets.

How to clean the device

Suitable cleaning agents and cleaning equipment

ATTENTION

Aggressive descaling agents

Unsuitable descaling agents may cause damage to the device.

- ▶ Only use Geberit AquaClean descaling agents to descale the device.
- ▶ Refer to the “Descaling the device” section.

ATTENTION

Aggressive and scouring cleaning agents

Cleaning using aggressive and scouring cleaning agents can cause surface damage.

- ▶ Use Geberit AquaClean cleaning agents.
- ▶ Pay attention to the cleaning and care instructions.

Using the Geberit AquaClean cleaning set is recommended, as this set includes a ready-made cleaning agent that is ideal for cleaning all Geberit AquaClean surfaces.

Recommended properties of suitable cleaning agents and cleaning equipment for best cleaning results:

Symbol	Properties of suitable cleaning agents
	Skin-friendly
	Cleaning agents are permitted to have a low acid content, e.g. diluted citric acid
	Low-foaming
	Liquid
	Water-dilutable

Symbol	Suitable cleaning equipment
	Soft, fine-pored sponges
	Lint-free, soft cloths which are free of dust
	Toilet brush

Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com

