
GEBERIT AQUACLEAN TUMA CLASSIC

GEBERIT



QUICK GUIDE

971.185.00.0(02)

For your safety

What should you avoid?

The product must be used as intended. Do not:

- leave the WC seat ring during the shower procedure
- place loads or objects on the WC lid
- immerse the remote control in liquid
- operate without plug for Geberit AquaClean descaling agent

Register your device

Warranty registration

Extend the warranty period of your Geberit AquaClean for free. Register for this within 90 days from the installation date.



In the third year of the warranty period, Geberit shall supply spare parts free of charge in the event of any material or manufacturing faults, provided the product has been installed and put into operation by an installation company.

By web link: https://www.geberit-global.com/landingpages/gac-onboarding/

By smartphone or tablet:

Via the Geberit Home App:

Android:


iOS:

If your country is not listed on the onboarding web page, please consult the list of contact information and websites. → See "Contact".


18014408390408587 © 12-2025
971.185.00.0(02)

Getting to know your device

The device at a glance



1	WC lid
2	Remote control with magnetic wall-mounted holder
3	WC seat ring
4	Lateral control panel with status LED
5	Spray arm with spray nozzle
6	Spray shield
7	Geberit AquaClean descaling agent (art. no. 147.040.00.1)



1	Filling opening with plug for Geberit AquaClean descaling agent
2	Power switch
3	Specification plate with serial number
4	Design cover

Some components and the consumables listed below can be ordered directly via the Geberit Home app or via the Geberit web shop.

Consumables	Article number
Geberit AquaClean cleaning set	242.547.00.1
Geberit AquaClean descaling agent	147.040.00.1
Geberit AquaClean descaling agent set (4 pcs)	147.047.00.1
Geberit AquaClean descaling agent set (10 pcs)	147.048.00.1
AquaClean Tuma spray nozzle	243.927.11.1
AquaClean Tuma remote control	245.368.01.1

18014408390408587 © 12-2025
971.185.00.0(02)


Operating concept

About the operating concept

The shower toilet can be operated via the lateral control panel or the Geberit Home app.

Front side of the remote control

All functions for daily use can be operated from the front side of the remote control.




1 <Shower> button: start and stop the spray functionality.

2 <+>/<-> buttons: increase or decrease the spray intensity.
<+> and <-> buttons: start and stop the oscillating motion during the anal shower.

3 Status LED (only visible if required)


Rear side of the remote control



1 Battery compartment

Lateral control panel

The shower toilet functions of the device can be operated from the lateral control panel.



1 <+>/<–> buttons: increase or decrease the spray intensity
2 Status LED
3 <Shower> button: start and stop the anal shower

Downloading the Geberit Home app

Download the Geberit Home app free of charge from the respective App-Store:

1 Open the App-Store on your smartphone.

2 Enter ‘Geberit Home’ in the search field.
✓ The Geberit Home app is displayed.



3 Download the app.
✓ The app is downloaded and displayed on your smartphone.

Alternatively, you can scan the respective QR code to download the Geberit Home app:

Android:

iOS:

18014408390408587 © 12-2025
971.185.00.0(02)

How to use the device

Using the anal shower

See user manual.




https://doc.geberit.com/972.476.00.0

Prerequisite

– You are sitting down on the WC seat ring.

▶ Briefly press the <Shower> button on the lateral control panel or on the remote control once.



Result

✓ The shower procedure starts.
✓ The anal shower starts in oscillating function. A small amount of water drains into the WC ceramic appliance via the overflow. The anal shower is active for 50 seconds.


You can stop the shower procedure early by pressing the <Shower> button once again.

Setting the spray intensity

Prerequisite

– The shower procedure is running.

▶ Press the <+> button to increase the spray intensity. Press the <–> button to decrease the spray intensity.



Result

✓ The shower spray becomes stronger/weaker.

You can set the spray intensity in 5 stages.

Setting the spray arm position

Female users should set the spray arm position of the spray functionality to their ergonomic conditions so that it does not compromise the natural protection of the vaginal area.

Prerequisite

– The shower procedure is running.

▶ Use the Geberit Home app to position the spray arm.

Result

✓ The spray arm is optimally positioned.

You can set the spray arm position in 5 stages.

Saving a personal user profile in the Geberit Home App

Prerequisite

– The current version of the Geberit Home app is installed on your smartphone.

– The Geberit Home app is running.

– You are within the detection range of the shower toilet. User recognition does not have to be activated.

1 Enter your personal settings.

2 Save your settings in the Geberit Home app.

Result

✓ Your personal user profile is saved onto your smartphone.

✓ The settings apply to all connected shower toilets.

18014408390408587 © 12-2025
971.185.00.0(02)

How to clean the device

Suitable cleaning agents and cleaning equipment

ATTENTION

Aggressive descaling agents

Unsuitable descaling agents may cause damage to the device.

- ► Only use Geberit AquaClean descaling agents to descale the device.
- ► Refer to the “Descaling the device” section.

ATTENTION


Aggressive and scouring cleaning agents




Cleaning using aggressive and scouring cleaning agents can cause surface damage.

- ► Use Geberit AquaClean cleaning agents.
- ► Pay attention to the cleaning and care instructions.

Using the Geberit AquaClean cleaning set is recommended, as this set includes a ready-made cleaning agent that is ideal for cleaning all Geberit AquaClean surfaces.

Recommended properties of suitable cleaning agents and cleaning equipment for best cleaning results:

Symbol	Properties of suitable cleaning agents
	Skin-friendly
	Cleaning agents are permitted to have a low acid content, e.g. diluted citric acid
	Low-foaming
	Liquid
	Water-dilutable

Symbol	Suitable cleaning equipment
	Soft, fine-pored sponges
	Lint-free, soft cloths which are free of dust
	Toilet brush

Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com

18014408390408587 © 12-2025
971.185.00.0(02)