





QUICK GUIDE



Getting to know your device

The device at a glance




- 1 WC lid
- 2 Specification plate with serial number
- 3 Basket filter
- 4 Lateral control panel with status LED
- 5 WC seat ring
- 6 Mains connection cable with plug
- 7 User recognition
- 8 Spray arm with spray nozzle
- 9 Drain screw
- 10 Spray shield

Operating concept

About the operating concept

The Geberit AquaClean shower toilet can be operated using the lateral control panel.

Lateral control panel



- 1 Storage water heater LED display
- 2 <Storage water heater function> button: economy mode/ON/OFF
- 3 <+>/<-> buttons: increase or decrease the spray intensity
- 4 <Shower> button: start and stop shower

What should you avoid?

The product must be used as intended. Do not:

- use aggressive and scouring cleaning agents that can damage the surface
- place loads or objects on the WC lid
- stand on the WC lid or WC seat ring

How is this product used?

The product is suitable for the following application purposes and areas of use:

- as a shower toilet:
 - for cleaning the anal area
- for installation in heated indoor areas
- for connection to the drinking water system
- for operation with water from reverse osmosis systems


WC seat ring and lid with soft-closing mechanism



Dampers cushion the WC seat ring and lid noiselessly and slow down closing. The seat ring and lid open just like on any normal WC.



Do not press the WC seat ring and lid down with your hand. This will damage the dampers.



How to use the device


Using the anal shower

Prerequisite

- You are sitting down on the WC seat ring.



Briefly press the <Shower> button on the lateral control panel.



Result

- ✓ The shower procedure starts and stops after 20 seconds.




You can stop the shower procedure early by pressing the <Shower> button once again.

Set the spray intensity

Prerequisite

- The shower procedure is running.

- ▶ Press the <+> button to increase the spray intensity. Press the <-> button to decrease the spray intensity.



Result


- ✓ The shower spray becomes stronger/weaker.



You can set the spray intensity in 5 stages.

Switching the storage water heater function on and off

- ▶ Press the <Storage water heater function> button repeatedly until the LED on the control panel shows the desired status (economy mode/ON/OFF).



Result

- ✓ The LED on the control panel indicates whether the storage water heater function is switched on or off or whether it is set to user recognition (economy mode). → See Status LED on the lateral control panel.

Cleaning and care

Suitable cleaning agents and cleaning equipment

ATTENTION

Aggressive and scouring cleaning agents

Cleaning using aggressive and scouring cleaning agents can cause surface damage.

- ▶ Use Geberit AquaClean cleaning agents.
- ▶ Pay attention to the cleaning and care instructions.

Using the Geberit AquaClean cleaning set is recommended, as this set includes a ready-made cleaning agent that is ideal for cleaning all Geberit AquaClean surfaces.

Recommended properties of suitable cleaning agents and cleaning equipment for best cleaning results:

Symbol	Properties of suitable cleaning agents
	Skin-friendly
	Cleaning agents are permitted to have a low acid content, e.g. diluted citric acid
	Low-foaming
	Liquid
	Water-dilutable

Symbol	Suitable cleaning equipment
	Soft, fine-pored sponges
	Lint-free, soft cloths which are free of dust
	Toilet brush



Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com