


MAINTENANCE MANUAL

INSTANDHALTUNGSANLEITUNG

MANUEL D'ENTRETIEN


ISTRUZIONI PER LA MANUTENZIONE

**KNOW
HOW**
INSTALLED







1





2




3




4



5




6




2




1





2



3




4




244.244.00.1

3


1




2





3





4






i



240.771.00.1





	A	B
 / 		
7.5 / 3 l	6	20
6 / 3 l	5	20
4.5 / 3 l	3	20
4 / 2 l	2	15



Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com